



Initially install FAE with the all-thread as shown above on left. Use oil or grease on the threads to prevent seizing (even cooking oil works). You can measure the all-thread bolt and cut accordingly, or you can mount the all-thread bolt and cut off the excess in place. If you cut the all-thread bolt before installation, place a nut on the bolt so you can unscrew it after cutting to clean up the threads. Once you are pleased with the installation tighten the nuts.

If you ordered the cover sleeve, cut the sleeve to exact length as shown in the picture on the right. Install the sleeve over the all-thread bolt (with a washer on the bottom) as shown above on right.

WARNING: Make sure that the lag bolts screw through 2 layers of wood as shown in the picture. Also be careful to not screw through the top of the swim platform.

We are pleased to answer your installation questions: call 512.647.7321

FAE Teak Platform Install 8/30/10